


The "360" Container Ventilation System


Installation Instructions

Step

- 1) Once the vent locations are determined, mark the port openings as per the cut-out instructions for both the Exhaust and the Intake, as below.



- 2) Cut the rectangle holes, clean off filings.
- 3) Prep the mounting surfaces with an abrasive pad or 180 grit sandpaper. Clean thoroughly and apply rubbing alcohol (IPA) diluted by 50% water. Dry with a clean rag
- 4) Remove the tape backing on the vents and press the vents in place



- 5) Press well to make sure initial contact is made. Cure is secure at 40% (after 20 minutes). The "Exhaust Driver" has two parts, port then cover. Intake has one part. The 3M tape takes about 24 hours to cure completely.

- 6) The commercial grade tape has great adhesion properties and provides a good seal. An exterior sealant is still required for the top of the intake and the top and bottom of the adapter plates (if required). For the extra minute it takes, we suggest applying a bead of sealant around the outer edges of all the vents and parts.

